




EZ-ZONE[®] PM to ACCESIO Converter Model USB-485 USB to RS-485 Adapter using Standard Bus



RS-485 Half Duplex (2-wire).
Connections between +TX and
+RX pins 2 & 9 and between -TX
and -RX pins 3 & 1 have to be
made in the external cable.

PC Software Protocol - Standard Bus
EZ Configurator

Data format
38,400 baud
8 data bits
no parity
1 start bit
1 stop bit

1 & 3
2 & 9
5

Mating female
DB-9 connector
required

Use twisted pair wires such as Cat 5 cabling.
Do not route with power carrying conductors.
Daisy chain wire up to 16 EZ-ZONE[®] devices.

0847-0251-0000

<http://acesio.com/>

Watlow
1241 Bundy Blvd
Winona, MN 55987
Telephone (507) 494-5656
2010 Watlow Electric Manufacturing Company

RGH 04-02-2015