


# Ring Terminal Thermocouple



The nickel terminal can be placed beneath existing screws or bolts to permit surface temperature measurement.

\* Only available with 24 gauge wire.

[www.zesta.com](http://www.zesta.com)



**Ontario (Head Office)**  
 212 Watline Ave  
 Mississauga ON, L4Z 1P4  
 T: (905) 568-3100  
 F: (905) 568-3131

**Québec**  
 2337 rue Guénette  
 St. Laurent QC, H4R 2E9  
 T: (514) 334-4744  
 F: (514) 334-0834

**Alberta**  
 4754-14 Street NE  
 Calgary AB, T2E 6L7  
 T: (403) 291-1156  
 F: (403) 291-2630

**British Columbia**  
 55B Fawcett Road  
 Coquitlam BC, V3K 6V2  
 T: (604) 525-7071  
 F: (604) 525-7797



[info@zesta.com](mailto:info@zesta.com)  
 1-800-755-5418